

Installation sheet

- Insert the graduated dips tick into the dip stick tube and leave it in contact against the bottom of the tank.
- Saw the dip stick to length at the top about 3 cm above the level at wich it emerges from the dip stick tube.
- Drill two 4,5 mm holes in the centerline of the dip stick in order to mount the gauge plug (see drawing).
- Insert the clip stick into the gauge plug and screw into the bayonet fully tighten and punch all the screws to prevent them stick tube into the tapping and tighten.
- Screw the tapped base of the plug to the G 1" ½ gauge sleeve.
- Bend at 90° end of the stick to avoid its full extraction providing the end to be shorter than drop pipe.

