

## MAINTENANCE

ITEM	QTY	DESIGNATION	PART N°
<b>Ball seals kit:</b>			<b>11 91 09 00 00</b>
4	1	Ball seal (PTFE)	12 96 06 00 10
6	1	Main seal (PTFE)	11 14 02 00 06
<b>Ball kit:</b>			<b>11 14 01 94 00</b>
5	1	Ball (316)	12 96 06 00 09
<b>Actuator coupling kit:</b>			<b>on request</b>
13	1	Coupling (CF8M)	-
15	1	Screw M6x20 (st st)	-
14	1	Washer W6 (st st)	-
12	1	Bearing (PTFE)	12 96 06 00 13
11	1	O'ring (Viton)	70 10 03 02 08
10	1	Spacer (PTFE)	11 14 02 00 03
9	1	O'ring (FEP/Silicon)	70 10 15 00 66
7	1	Spindle Gasket (PTFE)	11 14 02 00 01
8	1	Spindle (st st)	11 14 02 00 02
<b>Spindle seals kit:</b>			<b>11 14 01 92 00</b>
12	1	Bearing (PTFE)	12 96 06 00 13
11	1	O'ring (Viton)	70 10 03 02 08
10	1	Spacer (PTFE)	11 14 02 00 03
9	1	O'ring (FEP+Silicon)	70 10 15 00 66
7	1	Spindle Gasket (PTFE)	11 14 02 00 01
<b>Filter kit:</b>			<b>11 14 01 95 00</b>
3	1	Filter (st st)	-
2	1	Lock Ring (st st)	-

**Nb Perolo recommends :**

- The spindle seals should be changed simultaneously to maintain the ball valve spindle perfectly tight.
- Both ball gaskets should be changed simultaneously.
- Material of the parts are indicated for Stainless Steel Version. It may vary in HALAR Coated version. Please refer to HIGH CORROSION Catalogue for more details

