

Poppet o'ring replacement

① identification
PEROLO "NEATFLOW" 3"

② Pull out split pin

③ Release locking pin with 18 mm spanner

④ OPEN
Open valve by pushing down the handle

⑤ Pull out poppet firmly

⑥ Cut o'ring to be replaced

⑦ Cut o'ring with sharp tool

⑧ Pull out o'ring

⑨ Replace new o'ring

⑩

O'ring R 56 silicone encapsulated FEP
Ø 80,92 x 5,33